




Gauge Panel



Install gauges into panel- switches and knobs install into panel holes.
 Rocker switch changes illumination from green to blue.
 Knob adjusts brightness of illumination.
 Each gauge displays two pressures- one needle for each corner with two gauges.

